



[calculatoratoz.com](http://calculatoratoz.com)



[unitsconverters.com](http://unitsconverters.com)

## Bay Superelevation, Effect of Freshwater Inflow, Multiple Inlets and Wave-Current Interaction Formulas

Calculators!

Examples!

Conversions!

Bookmark [calculatoratoz.com](http://calculatoratoz.com), [unitsconverters.com](http://unitsconverters.com)

Widest Coverage of Calculators and Growing - **30,000+ Calculators!**  
Calculate With a Different Unit for Each Variable - **In built Unit Conversion!**  
Widest Collection of Measurements and Units - **250+ Measurements!**

Feel free to SHARE this document with your friends!

[Please leave your feedback here...](#)



## List of 24 Bay Superelevation, Effect of Freshwater Inflow, Multiple Inlets and Wave-Current Interaction Formulas

### Bay Superelevation, Effect of Freshwater Inflow, Multiple Inlets and Wave-Current Interaction

#### Bay Superelevation

##### 1) Depth given Water Surface Slope

$$fx \quad h = \frac{\Delta \cdot \tau}{\beta \cdot \rho_{\text{water}} \cdot [g]}$$

Open Calculator

$$ex \quad 11.91668\text{m} = \frac{1.49 \cdot 0.6\text{N/m}^2}{0.00000765 \cdot 1000\text{kg/m}^3 \cdot [g]}$$

##### 2) Superelevation

$$fx \quad \Delta_{BS} = a_o \cdot \left( \frac{\sin\left(2 \cdot \pi \cdot \frac{t}{T}\right)}{1 - \cos\left(2 \cdot \pi \cdot \frac{t}{T}\right)} \right)$$

Open Calculator

$$ex \quad 4.515067\text{m} = 4.0\text{m} \cdot \left( \frac{\sin\left(2 \cdot \pi \cdot \frac{1.2\text{h}}{130\text{s}}\right)}{1 - \cos\left(2 \cdot \pi \cdot \frac{1.2\text{h}}{130\text{s}}\right)} \right)$$

##### 3) Superelevation due to Varying Entrance Channel Cross-Section

fx

Open Calculator

$$S = a_o \cdot \left( 1 - \left( \frac{\left(\frac{a_B}{a_o}\right)^2}{4 \cdot \left(\frac{D_t}{a_o}\right)} \right) - \left(\frac{a_o}{m \cdot W}\right) \cdot \left(0.5 - \left(\frac{a_B}{a_o}\right) \cdot \cos(k) - \left(\left(\frac{3}{2}\right) \cdot \left(\frac{a_B}{a_o}\right)\right)^2 \right) + 4 \right)$$

ex

$$2.002888\text{m} = 4.0\text{m} \cdot \left( 1 - \left( \frac{\left(\frac{3.7}{4.0\text{m}}\right)^2}{4 \cdot \left(\frac{5.01\text{m}}{4.0\text{m}}\right)} \right) - \left(\frac{4.0\text{m}}{1.5 \cdot 52\text{m}}\right) \cdot \left(0.5 - \left(\frac{3.7}{4.0\text{m}}\right) \cdot \cos(185.2) - \left(\left(\frac{3}{2}\right) \cdot \left(\frac{3.7}{4.0\text{m}}\right)\right)^2 \right) + 4 \right)$$



#### 4) Tidal Amplitude in Ocean

$$fx \quad a_o = \frac{\Delta_{BS}}{\frac{\sin(2 \cdot \pi \cdot \frac{1}{T})}{1 - \cos(2 \cdot \pi \cdot \frac{1}{T})}}$$

Open Calculator 

$$ex \quad 3.995511m = \frac{4.51m}{\frac{\sin(2 \cdot \pi \cdot \frac{1.2h}{130s})}{1 - \cos(2 \cdot \pi \cdot \frac{1.2h}{130s})}}$$

#### Effect of Freshwater Inflow

#### 5) King's Dimensionless Variable

$$fx \quad Q_{r'} = Q_r \cdot \frac{T}{2 \cdot \pi \cdot a_o \cdot A_b}$$

Open Calculator 

$$ex \quad 0.574688 = 10m^3/min \cdot \frac{130s}{2 \cdot \pi \cdot 4.0m \cdot 1.5001m^2}$$

#### 6) Ocean Tide Amplitude using King's Dimensionless Variable

$$fx \quad a_o = \frac{Q_r \cdot T}{Q_{r'} \cdot 2 \cdot \pi \cdot A_b}$$

Open Calculator 

$$ex \quad 4.032897m = \frac{10m^3/min \cdot 130s}{0.57 \cdot 2 \cdot \pi \cdot 1.5001m^2}$$

#### 7) River or Freshwater Inflow to Bay using King's Dimensionless Variable

$$fx \quad Q_r = \frac{Q_{r'} \cdot 2 \cdot \pi \cdot a_o \cdot A_b}{T}$$

Open Calculator 

$$ex \quad 9.918428m^3/min = \frac{0.57 \cdot 2 \cdot \pi \cdot 4.0m \cdot 1.5001m^2}{130s}$$

#### 8) Surface Area of Bay or Basin using King's Dimensionless Variable

$$fx \quad A_b = \frac{Q_r \cdot T}{Q_{r'} \cdot 2 \cdot \pi \cdot a_o}$$

Open Calculator 

$$ex \quad 1.512437m^2 = \frac{10m^3/min \cdot 130s}{0.57 \cdot 2 \cdot \pi \cdot 4.0m}$$




9) Tidal Period using King's Dimensionless Variable 

$$fx \quad T = \frac{Q_r^3 \cdot 2 \cdot \pi \cdot a_o \cdot A_b}{Q_r}$$

Open Calculator 

$$ex \quad 128.9396s = \frac{0.57 \cdot 2 \cdot \pi \cdot 4.0m \cdot 1.5001m^2}{10m^3/min}$$

Multiple Inlets 

10) Maximum Velocity in Inlet Throat given Total Maximum Discharge 

$$fx \quad V_{max} = \frac{Q_{max} \cdot T}{2 \cdot \pi \cdot a_o \cdot A_b}$$

Open Calculator 


$$ex \quad 34.99849m/s = \frac{10.15m^3/s \cdot 130s}{2 \cdot \pi \cdot 4.0m \cdot 1.5001m^2}$$

11) Ocean Tide Amplitude given Total Maximum Discharge for Total of all Inlets 

$$fx \quad a_o = \frac{Q_{max} \cdot T}{2 \cdot \pi \cdot A_b \cdot V_{max}}$$

Open Calculator 


$$ex \quad 3.999828m = \frac{10.15m^3/s \cdot 130s}{2 \cdot \pi \cdot 1.5001m^2 \cdot 35m/s}$$

12) Surface Area of Bay or Basin given Total Maximum Discharge 

$$fx \quad A_b = \frac{Q_{max} \cdot T}{2 \cdot \pi \cdot a_o \cdot V_{max}}$$

Open Calculator 

$$ex \quad 1.500035m^2 = \frac{10.15m^3/s \cdot 130s}{2 \cdot \pi \cdot 4.0m \cdot 35m/s}$$

13) Tidal Period given Total Maximum Discharge for Total of all Inlets 

$$fx \quad T = \frac{2 \cdot \pi \cdot a_o \cdot V_{max} \cdot A_b}{Q_{max}}$$

Open Calculator 

$$ex \quad 130.0056s = \frac{2 \cdot \pi \cdot 4.0m \cdot 35m/s \cdot 1.5001m^2}{10.15m^3/s}$$




14) Total Maximum Discharge for Total of all Inlets 

$$fx \quad Q_{\max} = \frac{2 \cdot \pi \cdot a_o \cdot A_b \cdot V_{\max}}{T}$$

Open Calculator 

$$ex \quad 10.15044m^3/s = \frac{2 \cdot \pi \cdot 4.0m \cdot 1.5001m^2 \cdot 35m/s}{130s}$$

Wave-Current Interaction 

15) Angle Wave Orthogonal makes with Current in Non-propagated Wave Values on Forbidden Region 

$$fx \quad \theta = a \cos \left( F \cdot \frac{([g] \cdot d_T)^{0.5}}{V} \right)$$

Open Calculator 

$$ex \quad 3.767954^\circ = a \cos \left( 0.57 \cdot \frac{([g] \cdot 5m)^{0.5}}{4m/s} \right)$$

16) Channel Depth in Non-propagated Wave Values 

$$fx \quad d_T = [g] \cdot \left( \frac{\Omega \cdot T_p}{2 \cdot \pi} \right)^{\frac{1}{0.5}}$$

Open Calculator 

$$ex \quad 4.952265m = [g] \cdot \left( \frac{0.047 \cdot 95s}{2 \cdot \pi} \right)^{\frac{1}{0.5}}$$

17) Channel Depth in Non-propagated Wave values in Forbidden Region 

$$fx \quad d_T = \frac{\left( \left( V \cdot \frac{\cos(\theta)}{F} \right) \right)^2}{[g]}$$

Open Calculator 

$$ex \quad 5.000091m = \frac{\left( \left( 4m/s \cdot \frac{\cos(3.76^\circ)}{0.57} \right) \right)^2}{[g]}$$


18) Channel Velocity in Non-propagated Wave Values in Forbidden Region 

$$fx \quad V = \frac{F \cdot ([g] \cdot d_T)^{0.5}}{\cos(\theta)}$$

Open Calculator 

$$ex \quad 3.999963m/s = \frac{0.57 \cdot ([g] \cdot 5m)^{0.5}}{\cos(3.76^\circ)}$$



19) Effect of Current on Wave Height 

**fx**  $H = R_h \cdot H_A$

Open Calculator 

**ex**  $80\text{m} = 0.8 \cdot 100\text{m}$

20) Inlet Current Wave Height Factor 

**fx**  $R_h = \frac{H}{H_A}$

Open Calculator 

**ex**  $0.8 = \frac{80\text{m}}{100\text{m}}$

21) Non-propagated Wave Values in Forbidden Region Boundary Line 

**fx**  $F = \frac{V \cdot \cos(\theta)}{([g] \cdot d_T)^{0.5}}$

Open Calculator 

**ex**  $0.570005 = \frac{4\text{m/s} \cdot \cos(3.76^\circ)}{([g] \cdot 5\text{m})^{0.5}}$

22) Non-propagated Wave Values in Forbidden Region of Boundary Line 

**fx**  $\Omega = \left(\frac{2 \cdot \pi}{T_p}\right) \cdot \left(\frac{d_T}{[g]}\right)^{0.5}$

Open Calculator 

**ex**  $0.047226 = \left(\frac{2 \cdot \pi}{95\text{s}}\right) \cdot \left(\frac{5\text{m}}{[g]}\right)^{0.5}$

23) Wave Height Entering Inlet 

**fx**  $H_A = \frac{H}{R_h}$

Open Calculator 

**ex**  $100\text{m} = \frac{80\text{m}}{0.8}$

24) Wave Period in Non-propagated Wave Values 

**fx**  $T_p = \frac{2 \cdot \pi \cdot \left(\frac{d_T}{[g]}\right)^{\frac{1}{2}}}{\Omega}$

Open Calculator 

**ex**  $95.45676\text{s} = \frac{2 \cdot \pi \cdot \left(\frac{5\text{m}}{[g]}\right)^{\frac{1}{2}}}{0.047}$











## Variables Used

- $a_B$  Bay Tide Amplitude
- $A_b$  Surface Area of Bay (Square Meter)
- $a_o$  Ocean Tide Amplitude (Meter)
- $d_T$  Time Averaged Water Depth (Meter)
- $D_t$  Channel Depth (Meter)
- $F$  Non-propagated Wave Values of 'F'
- $h$  Eckman Constant Depth (Meter)
- $H$  Wave Height (Meter)
- $H_A$  Wave Height Entering Inlet (Meter)
- $k$  Phase Lag
- $m$  Bank Slope
- $Q_{max}$  Maximum Discharge of Total Inlets (Cubic Meter per Second)
- $Q_r$  River or Freshwater Inflow to a Bay (Cubic Meter per Minute)
- $Q_r'$  King's Dimensionless Variable for Freshwater
- $R_h$  Inlet Current Wave Height Factor
- $S$  Superelevation (Meter)
- $t$  Duration of Inflow (Hour)
- $T$  Tidal Period (Second)
- $T_p$  Wave Period (Second)
- $V$  Velocity in Channel (Meter per Second)
- $V_{max}$  Maximum Velocity in the Inlet Throat (Meter per Second)
- $W$  Channel Width corresponding to Mean Water Depth (Meter)
- $\beta$  Water Surface Slope
- $\Delta$  Coefficient of Eckman
- $\Delta_{BS}$  Bay Superelevation (Meter)
- $\theta$  Angle b/w Horizontal Velocity and Horizontal Wave (Degree)
- $\rho_{water}$  Water Density (Kilogram per Cubic Meter)
- $\tau$  Shear Stress at the Water Surface (Newton per Square Meter)
- $\Omega$  Non-propagated Wave Values



## Constants, Functions, Measurements used

- **Constant:** **pi**, 3.14159265358979323846264338327950288  
*Archimedes' constant*
- **Constant:** **[g]**, 9.80665  
*Gravitational acceleration on Earth*
- **Function:** **acos**,  $\text{acos}(\text{Number})$   
*The inverse cosine function, is the inverse function of the cosine function. It is the function that takes a ratio as an input and returns the angle whose cosine is equal to that ratio.*
- **Function:** **cos**,  $\text{cos}(\text{Angle})$   
*Cosine of an angle is the ratio of the side adjacent to the angle to the hypotenuse of the triangle.*
- **Function:** **sin**,  $\text{sin}(\text{Angle})$   
*Sine is a trigonometric function that describes the ratio of the length of the opposite side of a right triangle to the length of the hypotenuse.*
- **Measurement:** **Length** in Meter (m)  
*Length Unit Conversion* 
- **Measurement:** **Time** in Hour (h), Second (s)  
*Time Unit Conversion* 
- **Measurement:** **Area** in Square Meter (m<sup>2</sup>)  
*Area Unit Conversion* 
- **Measurement:** **Pressure** in Newton per Square Meter (N/m<sup>2</sup>)  
*Pressure Unit Conversion* 
- **Measurement:** **Speed** in Meter per Second (m/s)  
*Speed Unit Conversion* 
- **Measurement:** **Angle** in Degree (°)  
*Angle Unit Conversion* 
- **Measurement:** **Volumetric Flow Rate** in Cubic Meter per Minute (m<sup>3</sup>/min), Cubic Meter per Second (m<sup>3</sup>/s)  
*Volumetric Flow Rate Unit Conversion* 
- **Measurement:** **Density** in Kilogram per Cubic Meter (kg/m<sup>3</sup>)  
*Density Unit Conversion* 





## Check other formula lists

- [Bay Superelevation, Effect of Freshwater Inflow, Multiple Inlets and Wave-Current Interaction](#) [Formulas](#) 
- [Inlet Currents and Tidal Elevations Formulas](#) 

Feel free to SHARE this document with your friends!

## PDF Available in

[English](#) [Spanish](#) [French](#) [German](#) [Russian](#) [Italian](#) [Portuguese](#) [Polish](#) [Dutch](#)

7/19/2024 | 5:21:42 AM UTC

[Please leave your feedback here...](#)

